


WATCH DISPLAY

SETTINGS



A - Crown

This watch features minute and hour hands. Your mechanical watch will never need a battery. For proper timekeeping, you will have to wind your watch daily.

Before you set the time, please turn the crown (Part A) clockwise at position "0" until it feels tight. **NOTE: DO NOT** overwind your timepiece as it will damage the mainspring.

TO SET THE TIME

1. Pull the crown (part A) out to position "1" and rotate it to the desired time.
2. Once the correct time is set, push the crown back into "0" (zero) position.

FEATURES

- 19-jewel manual wind mechanical movement
- Gold-finished stainless steel case, crown & caseback
- 44mm case diameter
- 14" Gold-finished stainless steel chain
- Obverse American Eagle side of Walking Liberty half dollar
- Water resistant to 3 ATM

Visit us at www.stauer.com to learn more about the fantastic benefits of owning a Stauer Watch!

www.stauer.com

Stauer®

Afford the Extraordinary.

Stauer Liberty Eagle
Pocket Watch

INSTRUCTION MANUAL

