


WATCH DISPLAY**TIMESSETTING**

- A - 24 HOUR INDICATOR
 B - HOUR DIAL
 C - SUN & MOON DIAL
 D - CROWN

1. Pull the crown (D) out to position 1 to set the correct time. All hands and dials (Parts A, B, and C) are adjusted at this mode. Pay close attention the Sun & Moon dial while adjusting the time.

2. Once the correct time is set push the crown back to the zero (0) position.

IMPORTANT: Before the watch is worn for the first time, wind the crown, by hand, 15 to 20 cycles by rolling the crown clockwise (away from you) while in the "0" (zero) position.

IMPORTANT

Please remember to wear your Stauer watch each day to ensure its lifelong accuracy and dependability for your timekeeping needs. By continually wearing your Stauer watch, you will be taking full advantage of its state of the art automatic winding feature which allows the watch to function utilizing your everyday body movements. It can, however, be reactivated simply by the motion of being worn. When not wearing the watch, resting the watch on its side (with crown facing towards the ceiling) will help to keep more accurate time.

Visit us at www.stauer.com
 to learn more about the fantastic
 benefits of owning a Stauer Watch!

www.stauer.com

Stauer®
 HERITAGE OF ART & SCIENCE

STAUER WATCH
 INSTRUCTION MANUAL

